



NOTE:
 1. POWERHEAD TO BE AT RIGHT ANGLE
 TO GEAR BOX DRIVE SHAFT. (AS SHOWN)

Item	Part	Req'd	Description
1	600-0028	2	HEX BOLT (.38 X 1)
2	618-1000	2	SPRING LOCKWASHER (.38")
3	619-1105	2	SERRATED WASHER (.38")
4	24188	1	MOUNTING BRACKET WELDMENT
5	24425	1	STUD PLATE ASSEMBLY
6	31160	1	POWERHEAD (17:1)
7	80224	2	SPRING LOCKWASHER (.313")
8	610-1400	2	HEX NUT
9	24185	1	WORM DRIVE
10	617-0027	2	WASHER (.38") (SERIES "N") TYPE A
11	24428	2	COUPLER
12	643-0021	2	CLEVIS PIN
13	625-0013	2	COTTER PIN
14	606-0007	1	SCREW .25-20 X .50 TYPE "F"

TITLE: WORM GEAR ASSEMBLY		
COMPANY:		
MODEL #:	DATE:	DRAWING #:
31162	14 MAR 07	31161
REVISION LETTER:	ECN#:	APPROVED:
NONE	ESR-07FEB61339	GB